

INSTRUCTIONS

DENİZ MOTOR
TAMİR ATÖLYESİ
(Sultan ve Sultan Çarşısı)

STUART

Diesel Marine Engine

TYPES H₃M & H₃MR



PRICE
2/-

*This Book must
accompany Engine*


H₃M / _____
Enter the Engine No. here

In all correspondence quote Engine Number

Instr. Bk. 31 (2nd Edition)

DENİZ MOTOR
TAMİR ATÖLYESİ
Sultan ve Sultan Çarşısı

THE ROTOM
TYPEWRITER
BENJE ROTOM



BENJE ROTOM

TYPEWRITER

MADE IN U.S.A.

SECTION A

PREPARATIONS

- A1 **Fuel.** Light diesel oil or gas oil, conforming to B.S.S. 208/47, Class A.

Fuel containing any residual oil must not be used.

Fuel oil bought in bulk must be allowed adequate time to settle before transferring to the service tank; sludge and water in the oil will sink to the bottom. The draw-off tap should be a little above the bottom of the storage tank and a drain provided at the lowest point to enable the sludge and water to be drawn off occasionally.

When filling the service tank use a funnel with a fine gauze strainer.

- A2 The need for absolute cleanliness throughout the fuel system cannot be too strongly emphasized. The successful operation of a small diesel engine requires perfectly clean fuel. Dirt entering the system with the fuel will damage the working parts, block the holes in the injectors and result in a whole train of troubles.

- A3 **Priming the Fuel System.** Before starting for the first time and whenever the system has been allowed to run dry or has been dismantled, it must be primed. Take off the cover. Take out the screw on top of the fuel oil filter and operate the priming lever of the fuel lift pump until fuel containing no air bubbles issues from the top of the filter. Replace the screw. Next undo one of the delivery connections on the top of the injection pump, remove the delivery valve holder and lift out the delivery valve and spring. Operate the priming lever again until fuel flows. Replace the valve, spring and holder, making sure that they are perfectly clean, and retighten the delivery connection. Do the same with the other connections. Air in the pipes between pump and injectors will be cleared when the engine has been turned over a few times.

LUBRICATION

- A4 Use Heavy-Duty Oil of S.A.E. 30 Viscosity. Suitable oils are Vacuum Delvac 128, Shell Rotella GM 30, Watfield Central CR20, Duckham 20W/30, Esso Tri-Max HD30.

These oils contain additives which help to prevent the deposit of carbon and piston rings sticking.

Gearbox. Use the same oil.

Greasers. Mobil Hub Grease, Price's Amber A, Duckham's HPG, are suitable.

Water-Tight Greaser. A water-repellent grease such as Mobil Grease No. 2 (in the Tropics No. 3). This grease must not be used on the engine.

RUNNING INSTRUCTIONS

A2 Before Starting the Engine always:—

- (1) See that you have enough fuel. See that the spare fuel nozzle with holder is on board.
- (2) Check the lubricating oil level:—wipe the dipstick, replace and take it out again and check that level lies between the maximum and minimum marks. Check the oil level in the gauges.
- (3) Give all gears a slight turn.
- (4) Turn the switch to the "on" position.
- (5) Put the gear lever in neutral.

STARTING

A2 **Electrically.** Put the throttle lever vertical. Press the starter button; the engine should fire within a few seconds; if it does not, ease back the lever slightly. After a little practice the best position for starting will be found. Do not rotate the engine for more than about ten seconds at a time; allow the starter to come to rest before making another attempt, or the starter ring and pinion will be damaged. If the engine fails to start after several tries, take out the compression release valves and inject about a teaspoonful of lub. oil into each cylinder. Replace the valves (close them down tightly) and try again. The oil raises the compression and helps to seal the rings which may be dry if the engine has stood for a long time. After the injection of oil the engine will almost invariably start, even under very cold conditions. Persistently difficult starting indicates poor compression due to stuck rings or to wear.

A3 **Starting by Hand.** The fuel system having been primed, if the engine will not start electrically, or if the battery is flat, remove the compression release valves and turn the engine over a few times with the throttle open until the injectors are heard to be working. In cold weather put some oil into one cylinder, replace the compression release valves and swing the engine vigorously over compression.

Under freezing conditions, two teaspoonfuls of oil may be necessary.

A3 **Warming Up.** As soon as the engine has started, look at the oil pressure gauge. This will read about 40 p.s.i.; it falls to about 60 p.s.i. at full speed when warm and about 20 p.s.i. when idling. (If no pressure is shown stop the engine at once and investigate.) Bring the throttle lever back nearly to idling.

Give the engine a few minutes to warm up at low speed before putting on load; it will increase the life of the engine.

A3 At first no water will issue from the exhaust outlet because it is regulated by the thermostat. As this warms up water and steam will issue from the outlet.

Cylinders, when the engine is fully warmed up, are just too hot to be borne by the hand. The ammeter should show at least a small charging rate. A low rate means that the battery is up and only a trickle charge is passing.

- A10 **Getting under way.** Move the gear lever to ahead (or astern) as far as it will go; the gear lever must always be pushed right home; the throttle is used for controlling speed.

Never "slip on the clutch" nor try to go slowly by slipping the clutch, it will cause unnecessary wear.

- A11 **Stopping.** Put the gear lever in neutral and the control into the idling position, press the stop button until the engine stops.

Never turn off the fuel supply for this may cause air-locks and render re-priming necessary.

- A12 **Drain.** If there is risk of freezing, drain the cylinder jackets. The drain cock is on the starboard side of the engine just above the air winner. Loosen the valve caps of the circulating pump.

RUNNING

- A13 **Look occasionally to see that the cooling water or steam is coming through.**

Observe lubricating oil pressure and see that dynamo is charging.

- A14 **You can go from ahead straight into reverse and vice-versa without harm.** When the gear is engaged, the throttle can once more be opened.

Do not forget that with the engine at half or three-quarter power, fuel consumption will be much less than at full power whilst the reduction of speed of the boat will be slight.

Never allow the fuel tank to get quite empty. If you do you will have to re-prime the fuel system as described in para. A5.

- A15 **The engine must never, on any account, be overloaded.**

Overload is indicated at once by a change in the colour of the exhaust which is normally a faint blue. Overload changes it to black, caused by partly burned fuel. Running for any length of time in this condition results in stuck piston rings and clogged injector holes. There may be a momentary puff of black smoke when the engine is opened up suddenly, but this is harmless.

The gearbox will warm up to 80° C. (176° F.) on a long run; this is normal.

Remember to grease the stern tube bearing, half a turn every 1 or 4 hours.

QUICK WEEKLY EXAMINATION

A16 If possible, take the boat out for a few minutes' run. This is the best way of finding out whether everything is in order. In any case:—

Check Oil Level in sump and gearbox. Oil will be black, due to detergent doing its work.

Give a turn to gears on throttle gear and crankshaft pulley.

Clean strainer in seacock.

Check specific gravity (not less than 1.25) of battery electrolyte.

Run the engine; check oil pressure (about 60 p.s.i. at full speed).

See that dynamo is charging. Examine circulating water pump gland for leakage.

The usual indication that something is wrong is black smoke from the exhaust when engine is under load.

If exhaust is black, first check injectors. A C.A.V. Nozzle Setting Outfit (their part No. BT 125PA) is essential if one has any number of engines to maintain. Injectors can be checked on the engine (see para. B3) but it is much simpler to use the Nozzle Setting Outfit.

If injectors are in order, check air pump valves thus:—Put a hand over each air intake in turn. If the intakes on one is less than on the other, a valve is probably defective (see para. C10).

If this is not the trouble, remove exhaust manifold and examine ports for carbon build-up. If exhaust ports are blocked, also clean inlet ports and slusher (see Section C).

If the engine has run for any length of time with defective air valves the ports must be examined for carbon build-up.

SECTION B

MAINTENANCE

B1 Keep the engine clean. If this is done a leaking joint or connection will be seen and can be put right. Remember, pressures in fuel pipes are very high and fuel oil creeps everywhere.

The routine maintenance tasks are shown in the schedule. Do not neglect to carry them out or the engine may fail when you need it most.

Before working on the engine it is strongly advised that a preservative for the hands, such as Rosalene, be rubbed in; some skins are very sensitive to fuel oil.

The spare fuel injection nozzle and holder must always be in perfect condition. Obviously it is best to replace a nozzle which needs attention and recondition the defective one at leisure.

B2 Satisfactory injection depends on the correct working of the whole fuel system; satisfactory charging with air depends on the condition of the air pump, air passages and exhaust system, and the pressure in the cylinders depends upon the pistons, rings and bases being in good condition.

Loss of power, heavy knock and smoky exhaust all show that something needs attention.

- 83 **Fuel Injectors.** The quickest way to tell whether fuel injection is in order is to take out the compression release valves, open the throttle and gently turn the engine by hand.

The sound of the needles injecting can be heard.

A dirty injector is the most common cause of poor performance. Attend to the injectors regularly—say every month, whether the engine shows signs of the need or not. Use a C.A.V. nozzle testing outfit, if available, but if it is not, an injector can quite well be tested on the engine. Remove it with pipe complete and attach again so that the injector hangs over the side of the engine. Turn off the fuel; there will be enough in the filter for the test. Hold a piece of paper under the nozzle and turn the engine over by hand so that fuel is sprayed on the paper. Take care that your hand is not sprayed—the pressure is so high that the skin would be penetrated. There must be no dribble. The spray must be similar in direction and quantity from the two holes. If one is blocked (wholly or partially) or there are signs of dribble, fit the spare injector and recalibrate the original one without delay. After testing injectors, re-prime fuel system (see para. A2).

- 84 **Cleaning the Injector.** Perfect cleanliness is essential—the smallest particle of dirt can do serious damage.

Remove the nozzle from the holder by unscrewing the cap-nut. The nozzle valve is removed from the nozzle with the fingers; it and the body of the nozzle should be examined for signs of carbon deposit or discoloration. If the nozzle holes are blocked clean them with the picket, very gently to avoid breaking the slender wire (diam. .15 mm.). Both nozzle and needle valve should be allowed to soak in clean paraffin, and the valve should then be cleaned with a brass wire brush and then polished with a clean soft rag. Reassemble the valve in the nozzle while immersed in clean paraffin and work the two together until they are quite free. On no account attempt to grind in the needle valve. Detailed instructions are in the C.A.V. Handbook No. 2802/2. Unless you have access to a nozzle testing outfit do not interfere with the setting of the injector spring, as you will not be able to reset it to the correct pressure.

- 85 **Lubricating Oil Filter.** Loosen the bolt on top of the cover, remove the bowl and take out the element. Disassemble this by undoing the knurled knob underneath. Wash the components and also the bowl in paraffin. When reassembling do not overtighten the bolt or the bowl may be distorted and leak. After cleaning always, when the engine is first run, see that it is not leaking.

- 86 **The Water Pump** needs little attention beyond tightening the gland (just enough to prevent it leaking) : the ball bearing on the

TRoubles

115. If trouble should be experienced, deal with it promptly. The following schedule will assist in locating it and gives a guide to the remedy.

Systems—

Engine will not start—starter dead, or only turns sluggishly.

Probably cause, action to take—

- 1—Is battery charged? Are connections to battery and switches tight and clean?
- 2—Check starter motor (para. 113).
- 3—Starter pinion jammed; remove mud cap on starter and turn squared end of shaft.
- 4—Loosen decompressor valves, turn engine by hand a few times to circulate oil.

Starter motor rotates engine at speed but engine will not fire or, runs for a few revolutions and stops.

- 1—Fuel cock closed. Tank empty. Remedy obvious.
- 2—Fuel system needs priming (para. A5).
- 3—Decompressor valves leaking. Clean them and their seats.
- 5—Control lever wrongly set (para. A6).
- 8—Lack of compression. Piston rings dry. Engine too cold; inject oil into cylinders (para. A7).
- 10—Obstruction in fuel system or a dirty filter element (para. B6).
- 11—Engine needs decarbonising (para. C1).
- 12—Injection nozzles blocked or defective (para. B4).
- 13—Exhaust system blocked.
- 14—Fuel lift pump failure (para. D4).

Engine tends to stall when put into gear.

- 16—Idle stop up out of adjustment (para. D3).
- 17—Engine only firing on one cylinder. Check injectors (para. B3).
- 18—Defective fuel system: see 6, 10 and 14 above.

Engine runs unevenly.

- 19—Defective injectors (para. B3).
- 20—Injection pipes leaking, check tightness.
- 21—Air in fuel system ; prime it (para. A3).
- 22—Striking fuel pump plungers broken fuel pump spring (see C.A.V. Booklet).
- 23—Broken valve springs in air pump (para. C10).

Engine knocking, smoky exhaust, loss of power.

Try to locate cause ; then stop the engine as soon as you can.

- 24—Engine overloaded. Maximum speed stop out of adjustment (para. D5).
- 25—Injection needles defective (para. B3).
- 26—Engine needs decarbonising : rings stuck, pistons dry (see Section C).
- 27—Exhaust ports or pipes need cleaning (see Section C).
- 28—Air pump valves defective (para. C10).
- 29—Fuel pump timing slipped (para. D5). Engine up to No. 99 only.
- 30—Incorrect grade of fuel (para. A1).
- 31—Engine and shaft out of alignment (see Section E).
- 32—Damaged propeller.

Blue smoke from exhaust.

33—If continuous and excessive, rings may be stuck or engine may need a rebore.

Low oil pressure.

Stop the engine at once (para. A3).

- 34—Insufficient oil in sump.
- 35—Wrong grade of oil.
- 36—Defective gauge or pipe.
- 37—Relief valve plunger stuck or spring broken (para. F7).
- 38—Worn oil pump, worn bearings, slack unions, damaged oil pipes (paras. D10, D13, D16).

Engine overheating, insufficient flow of water.

- 39—Seacock turned off or seacock filter dirty.
- 40—Dirt under circulating pump valves.
- 41—Leak in suction pipe.
- 42—Defective thermostat (para. C7).

hinge-link needs greasing once or twice a year. See that valves and valve seats are in good condition.

To re-pack the gland, remove all old packing, then wrap the new packing seven times snugly round the plunger and make a clean cut across all turns with a razor-blade. Insert the rings so as to divide the packing into separate rings. Insert the rings one at a time and press each home, staggering the joints. Do not screw the gland down more than enough to prevent leakage.

After re-packing the gland, turn the engine carefully and see that the gland nut does not foul the hinge-link.

87 **The Crankcase.** Drain, then fill with about 6 pints of flushing oil. Run the engine for 15 minutes at no load and full speed. Drain once more and refill with new engine oil. Remove the magnetic plug at the forward end of the crankcase and clean it.

88 **Fuel Filter.** Take out the element. If it is very dirty, replace by a new one; do not attempt to clean it. Clearing results in dirt being transferred to the delivery side of the filter and into the fuel pump, where it will do serious damage. It is cheaper to buy a new pump.

89 **Lubrication of Dynamo.** Every 500 miles inject a few drops of engine oil into the hole marked "OIL" in the end of the bearing housing. For Commutator and bearing lubrication, see fig. 1.

The Starter Bearings need no lubrication.

90 **Inspection of Dynamo and Starter Brush Gear.** Check that the brushes move freely in their holders by pushing back the brush springs and pulling gently on the flexible connections. If a brush is inclined to stick, remove it from its holder and clean it with a petrol-moistened cloth. Be careful to replace brushes in their



FIG. 1



FIG. 2

original positions in order to retain the "bedding." Brushes which have worn so that they will not "hold" properly on the commutator must be replaced by new ones. The commutator should be clean, and should have a polished appearance. If dirty, clean it by greasing a fine dry cloth against it while the engine is slowly turned by hand. If this is not effective, moisten the cloth with petrol.

Method of shucking brush gear is illustrated in fig. 2.

- B11 Belt Tension.** Occasionally inspect the driving belts. Adjust by turning the generator on its mounting. Avoid over-tightening; there should be just sufficient tension to drive without slipping.
- B12 Control Box.** No maintenance nor adjustment will normally be required. If it appears that the battery is being over-charged, or if the battery does not remain in a charged condition, testing and adjustment of the equipment should be entrusted to a Lucas Service Depot or Agent.

MAINTENANCE SCHEDULE

- B13 Every ten hours' running or at weekly inspection.**

Give a run to the gears on the throttle gear and on the pulley at the forward end of the crankshaft, until if necessary.

Clean the strainer in the seacock.

Circulating Pump. If the gland leaks tap it round gently with a blunt instrument.

Batteries. Specific gravity of electrolyte should not be allowed to fall below 1.23. Top up with distilled water only. Vaseline the terminals to prevent corrosion.

Give a drop of oil occasionally to the joints of the control linkage.

If the chain shows rust or stiffness, remove and soak in Ruster oil for $\frac{1}{2}$ hour.

- B14 Every 250 hours.**

Service injectors (para. B1).

Drain sump and fill with new (not reclaimed) oil.

Clean lubricating oil filter element (para. B5). Examine exhaust ports and remove carbon (para. C1).

- B15 Every 500 hours or at end of season.**

Dynamo and Starter:—Lubrication and inspection of Brush Gear and Commutator (paras. B9 and B10).

Flush crankcase (para. B1). Examine fuel filter element (para. B9). Carry out decarbonising and top overhaul (Section C).

DECARBONISING AND TOP OVERHAUL

- C1 **Exhaust Ports.** Drain the cylinder block and take off exhaust manifold, first disconnecting the pipe from the water pump. Turn the engine to bring each piston to bottom dead centre before cleaning the ports. Remove all carbon with a scraper, taking great care not to damage rings or piston or to leave carbon in the cylinder.

If time is short, just carry out para. C1. If exhaust ports are badly choked, examine inlet ports also (para. C4).

- C2 **The Exhaust System.** Dismantle and beat out the exhaust pipes. Remove the silencer end and clean the inside; make sure that all the holes in the inlet and outlet pipes are clear.

- C3 **The Cylinders.** Remove the engine covers. Loosen the collar on the starting shaft and pull it forward, after removing the chain. Disconnect the fuel injection pipes and the water pipes from the thermostat.

Now undo the nuts and lift the cylinder head. Remove the joint and gently lift the cylinder block. Don't try to start the cylinder by driving a screwdriver between it and the crankcase—it will cause a leak from the air chest.

- C4 **Remove injectors and service them (C.A.V. Nozzle 20022), clean the carbon from the holes in the cylinder head and scrape the combustion chambers. Clean all the cylinder ports and polish the bores with a rag. If there is any brownish deposit of lacquer in the bores, remove it with methylated spirits and jeweller's rouge. Examine the bores for scoring and wear (para. D13).**

To clean the inlet ports, remove the small doors at each end of the cylinder block. If it is necessary to replace the joints under these doors, make sure that only those supplied by the maker are used. A joint of incorrect thickness will upset the control of the air flow into the cylinder (correct thickness is 0.015 in.)

*at least in some other definition
of the word*

C5 Take out the circlips and remove the piston pins with the extractor (part 3454). Do not mix up the pistons. As you take them apart mark cylinder and pistons with chalk so that you may be quite certain of assembling them as before. Remove the rings from the pistons.

C6 **Stack Rings.** Soak in methylated spirit and ease gently with a penknife in the gap. Remove by running a thin penknife round behind the ring—scrape them clean. Lay out the piston rings in order, and label them so as not to mix them up; each ring must go back in its own groove. Soak the pistons in methylated spirits to loosen the carbon and remove it from the top and the grooves by brushing carefully with a brass wire brush. Stack rings are the usual cause of loss of compression. Clean the inside of the pistons.

C7 Pistons are marked "E" on the side that faces the exhaust port. Assembled the wrong way, the gaps in piston rings will catch in the ports and break.

Clean all jointing compound off the bottom of the cylinder and the top of the crankcase and renew the joint between them. It is essential that it be absolutely tight.

Dismantle the thermostat housing. Put thermostat in nearly boiling water to check that it opens.

C8 Assistance is needed in replacing the cylinder block. Be careful to avoid damaging heads and piston rings. Put two wooden blocks below the cylinder block so that, if it suddenly slips over the pistons, it does not come down and pinch the fingers. Bring the pistons to mid-stroke and lower the cylinder block over the studs. While one person supports the weight of the block, with the steel bar, the other should guide the top of the pistons into the cylinder bores. Piston rings must be placed so that their open ends embrace the pins in the ring grooves. Squaring the rings, feed them into the chamber at the bottom of each cylinder. Make sure that the joint is lying flat and is evenly coated with jointing compound before the cylinder is lowered home.

C9 At T.D.C. the piston is level with the top of the cylinder bore; if it is not, adjust with extra cylinder bore joints.

Replace the cylinder head joint, so that the holes line up with the water holes, and then the head.

Tighten the cylinder head nuts evenly, working round several times to make sure that they are all tightened the same amount.

A good rule is to renew the gasket after about 1,000 hours' running but it may need replacing before that. Clean the flange face.



FIG. 3

- C10 Air Pump Valves (fig. 3 and fig. 5, para. F3). Remove the air ducts and blowers. Lower the nut securing the crankcase headcover. Take off the valve casings, tapping them gently with a block of wood to break the joint. The delivery valve rings are then exposed, the suction valve rings being in the casings. Examine the leaves to see that they are seating squarely over the slots in the rings. Lift each leaf by a matchstick through the slot and examine for cracks.

If any of the leaves show signs of damage, replace them. The inlet valve is secured to the valve casing by three screws (P). Take them out, knock off the valve retaining plate (R) and remove the valve ring assembly for examination. The delivery valve comes off the pump cylinder. Held between cylinder and valve casing, it is sealed by an O ring on both sides.

Valves should be dismantled on a large sheet of paper so that none of the parts be lost. Remove the screws holding the outer and inner rings together and then, laying the valve flat on the paper, carefully lift the outer ring: it will carry the "H" shaped valve spacers with it. The six leaf springs will jump-out as the outer ring comes off. Replace any damaged leaves: new leaves must be flat.

- C11 To reassemble, place the outer ring over the inner one and push the valve spacers half-way home, lifting the outer ring to do this. Having inserted a leaf in each slot, push the outer ring and the six spacers home. Replace the six counter-wash screws. Then wash the valve in petrol.

Do not hold any of the valve components in a vice; it is easy to distort them, and spoil the air seal.

If O rings are stretched or damaged they must be replaced.

D0. The work described in the following section should only be carried out by an experienced mechanic. It is best done when in clean dry surroundings. Take great care not to damage any of the components. Lay them out carefully as they are dismantled and do not dismantle any part of the engine unless it is really necessary.

Dismantling the Engine. The engine is dismantled in the following order; cylinder block and air valves have been dealt with in Section C.

- 1—Air Silencers and Air Ducts
- 2—Dynamo
- 3—Lubricating Oil Filter
- 4—Engine Cover
- 5—Hand Starting Gear
- 6—Circulating Water and Fuel Lift Pumps
- 7—Fuel Filter and Engine Cover End Plate
- 8—Fuel Injection Pump and Tappets
- 9—Governor Spring Housing and Linkage
- 10—Stator
- 11—Sump
- 12—Lubricating Oil Pump
- 13—Gearbox and Flywheel Housing
- 14—Flywheel
- 15—Cylinder Block, Head and Pistons
- 16—Connecting Rods
- 17—Crankcase End Cover, Camshaft and Driving Gears
- 18—Air Pump
- 19—Lubricating Oil System Piping
- 20—Partition Plate
- 21—Crankshaft and Main Bearings

D2. **Hand Starting Gear.** Remove the screw in the end of the crankshaft and the pulley. The ratchet ring on the chain wheel is engaged by three spring loaded dogs on the toe pulley.

D3. **Circulating Water Pump.** Before taking it off remove the fuel lift pump as its operating plunger is driven from an eccentric on the water pump spindle and must be withdrawn.

D4. **Fuel Lift Pump.** This is a standard A.C. Sphero Type Y to their drawing No. 1524215. It is similar to those on motor car engines and may be obtained from most garages. It will be necessary to bend the hand priming lever to clear the dynamo driving pulley. Failure is almost certainly due to the diaphragm having cracked. A diaphragm is among the spare parts when used, obtain another without delay.

D2 **Fuel Oil Pipes.** If dismantled make sure that the pipes are clean, that joint washers are in good condition and joints are tight.

D3 **Fuel Injection Pump.** Full instructions are given in the C.A.V. Handbook 200/4. Servicing this pump is a highly skilled operation so, if possible, send the pump to the engine makers. If it is necessary to service the fuel injection pump, first take off the end plate carrying the float.

D4 **A new or overhauled fuel pump has the elements correctly "balanced."** This means that the same amount of fuel is injected into each cylinder. If the pump has been dismantled, pay particular attention to the C.A.V. instructions on this point. It is easy to assemble the fuel pump rack and quadrants so that there is an error of one or two teeth in their engagement. Make sure that both always mesh on the two quadrants face in exactly the same direction and that the adjusting marks on the control quadrants and the regulating sleeves are together.

D5 **Fuel Pump Tappets.** The pump stands on the tappet guide rails tappets being retained in the guide by a screw engaging a slot. Examine the tappets, sockets and pins for wear, replace if necessary. Make sure that the tappets are not ground over and so no amount of adjustment of the adjusting screws in the top which engage the pump plunger guides. The screws affect the timing; it is possible to smash the pump if the screws are not positioned correctly. For adjusting tappets, see para. D11.

D6 **The Pump.** Remove the pipe from the sump drain pump. There is a paper joint between sump and crankcase.

D7 **Lubricating Oil Pump.** On a bracket on the underside of the crankcase. Before removing, disconnect the main delivery pipe and the scum pipe to the oil pump. Be careful not to bend it for a dipper to go into the trough in the air pump connecting rod.

The pump body, bracket and joint plate are held together by six screws. To remove the driving gear, it is held in a case with soft jaws so do not damage it, and the nut removed. Take off the wheel and key, the main shaft with screw comes out down wards. The drive screw runs on a lead specially ground by a push screw engaging with the flat on the spindle. This screw forces the oil feed hole in the spindle, supplying oil to the air pump.

The end clearance of the **main drive spindle** is **0.002 in.** If it exceeds 0.003 in. **or if the wear plate is worn,** send the pump to the makers for repair. To check end clearance, slip up the joint face, reassemble body, bracket and nut, try a straightedge across and check the clearance with a feeler gauge. Check the cover plate in the same way, adding the clearance, the total must be **0.002 in.** **Send to engine manufacturer.**

The oil screw is attached to the pump body by a chain. On refitting, take care that its bottom link is horizontal.

D01 **Flywheel Bleeding.** The gearbox and flywheel housing are attached to the crankcase partition plate by bolts and studs. Before removing them, place supports under the engine and gearbox to carry their weight.

D12 **The Flywheel.** Attached to a flange on the crankshaft by six bolts and a locating dowel, the flywheel may be withdrawn from the crankcase by means of two extractor bolts (tool M.28300). Examine the gear ring on the flywheel for damage and wear.

D13 **Cylinder Block, Head and Pistons.** Remove as described in para. C1. The diameter of a new cylinder bore is 2.75015 to 2.75023-in. When the wear at the top of the piston ring travel exceeds 0.003-in., i.e. when the diameter exceeds 2.750-in., new liners are required, or the existing liners honed and cross-hatch pattern fixed. **Makers standard oversize pistons and rings are +.000-in., +.0004-in. and +.0008-in. standard piston re-justification degree**

D14 **Liners** are honed to size after pressing in. It is recommended that re-sleeving be done by the makers, as, due to the ports, special methods are necessary. Generally, the piston will have as long a life as the liner and should be replaced at the same time. **The piston ring gap as fitted is 0.008 to 0.015-in.** Replace when the gap, with the ring in the narrow part of the bore, exceeds 0.002-in.

The figures of wear are approximate only. The design is too new for more exact ones.

D15 **Connecting Rods.** The connecting rod and its oilways should be very carefully cleaned. An oil duct leads to an annular groove around the small end bush, with four holes for lubricating the piston pin. Make sure that all these holes are clear.

The piston pin and small end bush should be checked for wear. **The diameter of the pin is 1.890 to 1.899-in.** A pin wears oval; when its minimum diameter falls below 1.890-in., it and the bush should both be replaced. The diameter of the bush is 1.89025 to 1.891-in. When it exceeds 1.892-in., it should be replaced.

Examine the big end bearing for pitting and scoring. The its surface may have worn off the upper half, but it may still be serviceable. The bore is 2.000 to 2.0015-in.; bearing shells should be replaced when the maximum bore exceeds 2.005-in.

When re-fitting, make certain that everything is absolutely clean. Dirt will result in the break-up of the bearing surfaces.

Connecting rods and caps are numbered, numbers toward the port side; this is essential. No. 1 rod is at the forward end.

D16 Crankcase End Cover. This carries the ball races supporting the crankshaft and camshaft. Remove the camshaft cover plate which encloses the camshaft ball race, screw two $\frac{1}{2}$ U.M.F. jacking screws (part M74009) into the holes on each side of the end cover and raise the cover off. Tap the end of the camshaft while doing this to shift the camshaft ball race.

On engines earlier than No. 100, be careful not to damage the crankshaft oil seal, so, before replacing the end cover take off the crankshaft nut.

D17 Crankshaft and Governor. The crankshaft cannot be taken out until the C.A.V. pump, tappet guide and governor spindle have been removed. To remove the governor spindle drive out the locking pin in the ball crank, take off the nut at the top of the spindle and lower spindle and operating fork into the crankcase.

If the crankshaft is tight in the rear ball race, gently tap it forward by means of a brass drift through the opening for the fuel pump in the top of the crankcase. The governor has two weights acting through a sliding sleeve and thrust bearing against the fork on the governor spindle. Ahead of the governor is the alloy cast iron driving gear.

The rear ballrace is a tight fit in the crankcase; it may be removed by heating the crankcase. It should be free when the temperature of the crankcase is near boiling point.

Examine the camshaft ball bearings for wear.

D18 Crankshaft and Main Bearings. Before removing the crankshaft detach the partition plate from the other end of the crankcase. The crankshaft end flange runs in the bore of the partition plate; an oil-tight groove prevents leakage.

Handle the crankshaft with great care; it carries the spiral gears driving the lubricating oil and water pumps and the spur wheel driving the camshaft. On engines before No. 100, the gears are locked to the crankshaft nut, and the camshaft driving gear has a round bore engaging with a cone on the water pump drive gear. This is for locking the camshaft. Crankshaft end flange is taken up by three washers on each side of the centre main bearing.

Remove the pipe which feeds oil to the forward bearing cap. Bearings caps are a tight fit in the crankcase; they are removed by the bearing cap extractor (part K1770) which is screwed into the $\frac{1}{2}$ B.S.F. hole in the centre of the caps. The cap of the centre main bearing is lined with copper-lead; all others are white metal. Caps and crankcase are numbered and must not be interchanged. Be careful not to mix the various bearing shells. Examine for pitting and wear. The bores are 2.0825 to 2.091-in. diameter. When a bore exceeds 2.09-in. at any point, fit new shells.

D19 Crankshaft Journals and Crankpin Diameters are 2.080 to 2.090-in. When one of them has decreased to 2.090-in. or when

the crank of journals or crankpins exceeds 0.0001 in., the crankshaft must be re-ground and undrilled bearings fixed.

Before re-assembly, clean the always and test that they are dead. The main bearing nuts should be tightened with a torque spanner to a torque of 500-lbs. in.

- D08 **Crankcase and Oilways.** Take the oil pressure relief valve out, clean it and flush out oilways in the crankcase and all oil pipes with petrol. Clean the air passages in the crankcase.

If a degreaser is available, use it for cleaning the crankcase before assembling the engine. Alternatively, wash thoroughly with petrol. Do the same to all other parts of the engine.

- D09 **Air Pump (Fig. 5, para. F3).** The air pump valves are dealt with in para. C10 and 11. After the valves have been removed take out screws (K) then remove cylinder and piston together with two packing screws (M2410) inserted into the tapped holes in each cylinder flange. The cylinders are spigoted into the crankcase with an O ring (H) in a groove around each cylinder. This ring must be a snug fit, to prevent leak. If it has stretched, or is damaged, replace it; wash-up it before inserting.

Remove these and gently ease the pistons off. They are marked "port" and "starboard." Replace with the markings the right way up.

At the starboard end of the yoke is the piston pin secured by circlips. Withdraw the pin and remove the yoke from the starboard side. The connecting rod is withdrawn after removing the crankcase and cover and the driving gears from the crankshaft. Examine white metal lining of the rod bearings for pitting and wear.

- D10 Fit the yoke with the connecting rod pointing to starboard, otherwise the oil jet will not lubricate the rod.

Reassemble piston and cylinder together, reversing the procedure described above. The screws, K, are specially made with a locking device. No other screws must be substituted. The piston rings are taper. The side marked "top" must be towards the top of the piston.

REVERSE GEARBOX

- D11 It is attached to the flywheel housing by six studs. Do not dismantle unless necessary for repairs.

To do so, first wedge the coupling at the engine and next to the flywheel, put the lever in gear, unscrew the nut at the after end, draw off the coupling and remove the key.

If an engine with reduction gear the reduction gear case is removed complete with driving shaft and gear in it. The gear, shaft and bearings are lifted out of the case together for the locknut is riveted to the shaft.

The rear bearing is held by a circlip and the outer race of this bearing may remain fixed to the case, so have a tray underneath to catch the balls and cage. Circlip, cover, drive gear and key, and the several thrust nuts are now drawn off the shaft. The thrust rim of outer race face each other.

DC4 Remove the control housing with the gear keys, take out the eccentric shaft screw and withdraw the shaft. This is just before the opening in the gearbox. Take out the screw Pt. 12861. At the other end of the shaft is a plug Pt. 12862 in which is a small screw. Take out this small screw which then enables you with a rod to drive the eccentric shaft out just sufficiently to clear the serrations on the shaft. The serrations are there so that fine adjustments of the eccentric shaft can be made by moving forward or backward one serration at a time. Lift out the operating fork.

To dismantle the primary shaft assembly carried in the flywheel housing, wedge the coupling against rotation and unscrew the nut. Withdraw coupling and key and carefully drive the shaft back through the ball race. The forward cone is pressed on to the shaft and held by two keys.

The double thrust race is removed by taking out the internal circlip and warming the flywheel housing slightly. An oil seal is pressed into the front end of the flywheel housing; be careful at this when re-assembly.

DC5 Note—in a few of the earlier gearboxes, the double thrust race is replaced by a single thrust race, with a thrust washer behind it. When assembling, the thrust washer must be placed with the relieved face towards the ball race, before the race is pressed in position. The shaft is then threaded through the ball race and the thrust washer. The ball race has the thicker edge of the outer race, (marked "drive") facing towards the engine.

DC6 The secondary shaft carrying the remaining moving parts of the gearbox is removed by driving it forward; take care not to damage the end of the shaft. The shaft, which carries the planet train, slips forward out of the clutch body which slides upon it on three keys. Do not disturb the planet train unless it is absolutely necessary. The planet pinions are retained by an end plate secured by six set-screws. Mark the planet pinions so that they go back the same as before. The planet cage rotates on the secondary shaft and is secured by a circlip.

DC7 To dismantle the clutch body and operating sleeve assembly, remove the large circlip securing the double thrust race in the body and tap the operating sleeve assembly forward and out of it.

To dismantle the sleeve, place two clamps over the double thrust race and the rear pressure plate to compress the springs enough for the circlip at the other end of the inner sleeve to be removed.

DC8 The part of the gearbox most subject to wear is the floating bush between the primary and secondary shafts. The outside diameter is 0.999 to 1.000 in. If it has worn to 0.996 in., re-new. The bore is 0.75075 to 0.751 in. Replace when it exceeds 0.751 in.

DC9 **Re-assembly.** Make sure that the ball thrust races are the right way round. In the case of the direct drive engine, there are two races at the after end of the gearbox. They must be assembled face to face with the thicker edges of the outer race marked "drive" facing outwards; in the induction gear engine, there are races on each side of the pinion and of the final output gearwheel :

they too must be assembled with the thrust side of the pins facing outwards.

Remove the flexible coupling disc if the holes are worn. Also examine the steady bush in the end of the crankshaft. This has a bore of 0.7505 to 0.7495-in. If it exceeds 0.752-in., drive out and replace; oil before assembling.

The gear control mechanism is "balanced." The force required to engage ahead and astern gear is equalized by turning the eccentric shaft, which has two flats at its port end. When the right position has been found, make the adjustments described in para. D14, the set-screw pin must point upwards. Lock it by the eccentric screw shaft.

Backlash in the control mechanism is eliminated by removing one or more of the paper joints from the underside of the gear control housing.

FUEL INJECTION SYSTEM

D10 **Adjusting the Fuel Injection Equipment and Control Mechanism.** This must be done with the greatest care. The successful operation of the engine depends upon correct injection.

D11 **Timing the Fuel Pump.** The spill-port of the injection pump is set to close 25 deg. before Top Dead Centre. This controls the moment at which fuel is injected into the cylinders.

To check the timing, remove the cover on the flywheel housing. There are two sets of marks on the flywheel, corresponding to the "top dead centre" and "injection point" of the two cylinders and a fixed pointer in the housing. Find the mark stamped TDC—C; 25 deg. ahead of it is another mark stamped IP—1. This must be opposite the pointer when delivery of fuel to No. 1 cylinder is about to begin. No. 1 cylinder is that furthest from the flywheel and is fed by the corresponding cylinder of the fuel pump.

Remove the fuel injection pipe to No. 1 cylinder and the delivery valve holder, valve and spring. Replace the delivery valve holder only, set the control to the full load position and operate the priming lever of the fuel lift pump, when fuel will flow out of the top of the delivery valve holder. Slowly rotate the engine in the direction in which it runs—clockwise when viewed from the forward end—until the fuel ceases to flow. This is the point at which the pump spill-port closes. At this point, the mark IP—1 is opposite the pointer in the flywheel housing when the timing is correctly set. Permissible error is 1½ deg. or 1-in. at the flywheel rim.

D12 On engines up to No. 99. To adjust the timing, loosen the crankshaft nut and tap the end of the crankshaft with a block of wood and hammer. This will free the cone on the crankshaft driving gear. The crankshaft may then be turned using a box spanner on the end nut. Set the flywheel to IP—1 and turn the crankshaft anti-clockwise until the spill-port closes and fuel ceases to flow. Tighten the crankshaft nut and re-check the timing, turning the engine in a clockwise direction. If it is correct drive up the crankshaft nut really tight, using a hammer on the spanner; re-check the timing.

On later engines there is no timing adjustment, but crankshaft driving gears must be assembled so that marks on the teeth of crankshaft and camshaft gears come together.

- 115 New re-assemble the delivery valve and holder of No. 1 cylinder and check the timing of No. 2 cylinder in the same way. If the timing of No. 2 cylinder is incorrect, i.e. if the two pump cylinders are not exactly at 180 deg. they may be adjusted by altering the height of No. 2 tappet. Remove the fuel pump and expose the tappets. If the timing is late, the tappet screw must be raised; if early, it must be lowered. Turning the screw through one flat (90 deg.) alters the timing by approximately 1 degree. Make sure that the locknut is securely tightened after adjustment. If the tappets have been disturbed, they must be adjusted to the correct height. Remove the pump, turn the engine until both tappets are at the bottom of their travel and with the gauge (part 1222) supplied, set the tappet screws so that they lie 5/16-in. above the top face of the tappet carrier, with the paper just removed. It may be necessary subsequently to alter these settings slightly to get both split timings correct.

- 124 **Balancing the Fuel Pumps.** A new injection pump is sent out correctly "balanced," i.e. the delivery of fuel from the two cylinders is equal at any rack setting. Provided the instructions given in para. D7 have been correctly followed, an overhauled pump should also be in balance, but it is well when an engine has been given a complete overhaul to check the balance by the exhaust temperature. Two 1/4-in. B.S.F. Flugs in the top of the exhaust manifold cover holes provided for the use of thermometers.

Run the engine on load and after giving it a few minutes to warm up, read the thermometers. They should be within 30-deg.F. (15 deg. F.) of each other at full load. Change them over and read them again and take the average of the two readings for each cylinder. If one cylinder is giving a low temperature, it is not receiving enough fuel. Remove the cover plate on the starboard side of the pump and loosen the damping screw in the quadrant of the pump cylinder corresponding to the low temperature. With a small screwdriver (nail will do) turn the regulating sleeve slightly anticlockwise. Retighten the quadrant damping screw and re-check the temperature.

The full load delivery of the fuel pumps is 14.6 cch. min. per stroke, or 9.8 c.c. in 400 strokes; if a pump tester is available the elements may be balanced at this delivery.

THROTTLE CONTROL MECHANISM

- 125 With the boat under way and the engine well warmed up, check engine speed by means of a tachometer, then push the fuel pump rack farther open until the exhaust turns black. Normal full throttle speed must be at least 50 r.p.m. lower.

To adjust the maximum load position, slack off the ball joint at the end of the rod linking the throttle lever to the governor, loosen the locknut on the rod, and turn the ball joint. To raise speed, shorten the rod; to lower it, lengthen it. Adjust idling speed

by the idling stop on the governor spring housing. Screwing it in raises speed. The engine should idle at about 500 r.p.m. Check that it is possible to stop the engine by pushing the stop button.

Do not try and get too much out of the engine, particularly if the boat may be in the hands of unskilled people; any possibility of overloading the engine must be avoided. Fat that would soon result in deterioration and rapid deposit of carbon.

SECTION E

INSTALLATION INSTRUCTIONS

- E1 A special book 'Installation Instructions' (No. 28—price 2/4 for marine engines in general) is available—the following notes deal with special points of interest.

Keep all the equipment scrupulously clean. Serious trouble can be caused by dirt getting into the component parts of the fuel system before use.

Put on one side tools and handbooks to hand to the owner.

Please return the packing crate and cases and inform us of despatch.

- E2 **Slinging.** There are three slinging eyes on the engine—one on each side of the flywheel casing and one at the forward end of the cylinder block—seen when the cover is off. Do not sling by passing a rope round the dynamic pulley.

- E3 **Engine Bearers.** Angle of installation must not exceed 12 deg. The engine bearers should be sloped for the square bronze blocks, the studs screwed home and the locking pins inserted.

Curve out a dip in the bearer on the port side so that the lubricating oil line is easily accessible.

- E4 The engine must be accurately in line with the propeller shaft when the boat is in the water. Alignment, though perfect when the engine was installed, may become incorrect, due to slight movement in the structure of the boat; no boat is perfectly rigid.

- E5 The alignment should be checked a few days after installation. Take off the coupling nuts and slide the propeller shaft back. Reverse the shaft. The coupling must run truly; if not, the shaft is bent. Slide the shaft forward; it should meet the coupling on the engine truly. Test with feelers between the faces of the coupling in four places, top and bottom and both sides, to make certain that the two shafts are truly in line.

SECTION F

GENERAL DESCRIPTION

F1 The engine is described as if it were installed in a boat. The flywheel and gearbox are at the stern end; hand starting gear at the forward end. (Hand starting at the other end cannot be arranged). "Port Side" is on the left, "Starboard" on the right.

The Stuart RC Engine is a two-cylinder two-stroke engine of the "loop scavenged" open combustion chamber type, air being admitted and exhaust released through ports in the cylinder wall. Air for scavenging and combustion is supplied by a reciprocating air pump at the forward end of the engine.

The reverse gearbox is in two forms:—direct drive, type HLM, and with reduction gear, type RCMB.

Fig. 18, inside the back cover is a cross-section of the engine.

F2 The Crankcase is a water-cooling aluminium alloy casting. The flywheel is enclosed in a housing attached to the crankcase. The crankshaft, of high-duty cast iron, runs in three steel-backed thin-walled main bearings. The lower half of the centre main bearing is copper-bushlined; all others are white metal. There is a ball bearing at the forward end. Main and connecting rod bearings are fed with oil under pressure.

An eccentric on the crankshaft drives the air pump; all auxiliaries are at the forward end.

The Crankshaft on which is the governor, is driven through spur gears and runs on ball bearings.

The Cast Iron Sump holds about 1 gallon of oil; lubrication is by a submerged gear pump.

The Cast Iron Pistons have four compression and one scraper ring; the top ring chromium plated. The cylinder block and head are cast iron; dry liners of alloy iron are used. They stand proud of the cylinder block .002-.003 in. to ensure a gas-tight joint. There are accurately machined inlet and exhaust ports in the liners.

Air at about 2 p.s.i. is delivered by the air pump to an air chest at the bottom of the cylinder block whence vertical passages lead to the inlet ports.

The combustion chamber is in the cylinder head. Cylinders and fuel pump are enclosed in a cast steel case. A cast iron exhaust manifold is on the starboard side. Each cylinder has a compression relief valve.

When the engine is running the down-stroke of each piston first uncovers the exhaust port and the pressure falls to near atmospheric.




Fig. 4. How low air is transferred from air pump to ports in opposite lower air ducts in crankcase and opposite block.

A little lower down the piston uncovers the inlet ports, compressed air rushes in, sweeps the remaining spent gas out of the cylinder and charges it with fresh air which, as the piston rises, is compressed.

Air Pump. Fig. 3 is a transverse section. Two aluminum pistons connected by a yoke (B), are driven by a parallel connecting rod (C) from the eccentric (D) on the crankshaft. Each piston (A) has two compression (E) and one scraper ring (F). The cylinders (G), cast iron, are splined into the crankcase and sealed by an O ring (H).

Air enters through silencers and air ducts. "Circulox" suction and delivery valves are used.

The valves are in two concentric rings, the suction valves inside the delivery (figs 3 and 5). Air, entering the centre of the valve, passes through six slots covered by thin beryllium-copper leaf springs. Suction lifts the leaves and, when delivery begins, they spring back and seal the slots. The delivery valve is similar, opening under pressure and closing when the suction stroke begins. It is sealed by an O ring on each side (I).

Compressed air passes from inside the valve casing through slots in the pump cylinder flange to an annular cavity in the crankcase, thence through a transverse passage above the centre main bearing to the air duct (Fig. 4).

E6 **Wear Tube Bearings.** The shaft must not run in a rubber bearing except under water. Oil shaft and bearing with a vegetable oil such as Castor Oil before inserting the shaft and substitute as soon as possible. Do not use mineral oil.

E7 **Fuel System.** Make the fuel pipe short and direct to avoid air locks.

E8 **Exhaust System.** The satisfactory performance of any two-cylinder diesel engine may be affected quite seriously by a badly installed exhaust system. So follow these instructions exactly; it is worth while taking a little extra trouble to get a good installation. Have as few bends as possible, and use bends, not elbows.

A 3-ft. length of galvanized pipe between the engine and silencer is ideal; it may have to be slightly more on occasion but do not, on any account, exceed 5-ft. There is no objection to reducing the length of this pipe. For the tailpipe, 1½-in. hose is used. Keep this as short and straight as possible. It is permissible to fit the exhaust outlet just below water level, if there is any possibility of the sea entering the exhaust system (as in a following sea) a twin neck must be fitted.

There must be a fall of at least 18-in. from the exhaust manifold to the silencer to avoid any possibility of the cooling water, injected into the silencer, finding its way into the engine. There is no objection to a moderate rise to the outlet. The flow of exhaust gas through the system will carry the water with it.

E9 **Cooling Water System.** The STUART seawork has three connections toward the top end, to one of which the vent pipe is connected. If the seawork is not vertical, connect to the uppermost one. Carry the pipe well above water level and bend the top over.

The lower connection on the seawork is connected to the suction of the circulating pump and the sea half-way up the board to the lower connection on the thermostat. A pipe from the upper connection on the thermostat is connected to the silencer. The thermostat cover may be in any one of three positions as may be most convenient for neat pipe-work.

The seawork must be accessible; the strainer will need cleaning. The suction pipe should be short, but it must have some flexibility; a reinforced rubber pipe is sometimes used. The inlet must be placed where the water passing it is "calm"—low down, not too close to the stern nor near the keel, or there is a risk of air bubbles causing failure of the pump.

If the engine is below water level, suction may be erratic unless special valves, cups and springs are used. These can be supplied.

The solderless pipe unions used for making the water pipe connections are fitted as follows:—

Thread nut on pipe, push olive on pipe until 1-in. pipe projects. Place the pipe in the union, see that it is quite square with the union. Screw down the nut. Do not bend the pipe close to the union, leave at least 1/2-in. of pipe straight.

- E10 Gear Lever.** Gear lever may be fitted in either of two positions, whichever is more convenient. It is secured by means of a cotter. To change the position, take out the cotter and turn the lever over.




FIG. 5

FUEL INJECTION

F4 The pump is on top of the crankcase. It is operated by tappets driven by the camshaft.

The pump delivers fuel through steel pipes to the injectors in the cylinder heads. They open at a pressure of 2,500 p.s.i. and spray fuel through two-hole nozzles into the highly compressed and therefore heated air.

The governor controls the position of the fuel pump rack, determining the amount of fuel delivered to the engine. The throttle control bears against the governor spring, so the engine is always under control of the governor; it cannot race and will run quite steadily at all speeds.

F5 **Lubrication.** The gear pump is submerged, drawing oil through a gear strainer.

Oil is delivered to a full-flow filter on the port side of the engine. From the filter, drilled holes carry oil to the center and rear main bearings and to a pressure relief valve; this, covered by a plug, is at the after end of the crankcase on the port side.

A pipe feeds the forward main bearing. Oil from the front and rear main bearings passes through passages in the crankshaft to the big ends, these doing supply to the small ends.

A hole in the fixed spindle of the driven gear in the pump coincides each revolution with a hole in that gear and oil is sent through a pipe attached to the top inside face of the crankcase, into a trough in the air pump-connecting rod feeding the big and small end rod bearings. The camshaft, governor, water pump spindle and the various driving gears are all lubricated by splash.

The oil filler is on top, the dipstick is on the starboard. A magnetic plug at the forward end of the sump picks up any iron and steel particles that may find their way into the oil. A connection is provided for an oil pressure gauge at the after end of the crankcase, above the starter.

On the flywheel casing is a hand-pump for draining the sump.

- F6 **Governor.** The governor acts upon a spindle carried in a standard screwed into the top of the crankcase. On the top end of this spindle is a bell-crank (A), one arm of which is linked to the fuel injection pump rack (B), while the other arm bears against the governor spring end cap (C) (Figs. 6 and 7).

The governor spring is in a housing (D) on top of the crankcase. One arm of the governor control lever (E) is linked to the throttle lever. A slot in the other arm of the control lever engages with a pin so as to move the governor push rod (G); this is underneath the governor spring. This pin also protrudes into a slot in the inner governor spring end cap.

If the throttle lever is moved anti-clock, the governor spring is compressed by the movement of the inner end cap and the speed of the engine increases.

Turning it the other way as far as it will go reduces speed to "dead slow." Then, by pressing the red stop-button on the end of the link rod the pin (H) bears against the governor bell crank moving the fuel pump rack to the no-fuel position, stopping the engine.

- F7 The injection pump is supplied with fuel by a lift pump on the forward end of the crankcase, so the fuel tank can be below the level of the pump. The lift pump delivers fuel through a filter under the engine cover. Fuel leaking from injectors returns to the fuel filter.

- F8 **Cooling.** The engine is water-cooled. The plunger pump is on the port side, forward end. At 1,500 r.p.m. it delivers about 80 gallons of water per hour to a connection in the exhaust manifold, thence into the cylinder block below the exhaust ports. Water passes round the cylinders and up to two brass throbbles pressed into the cylinder head. Thence direct water around the injectors; water then passes to a thermostat at the after end of the head.

There are two outlets from the thermostat housing. When the engine is cold, most of the water leaving by the lower outlet returns to the scavenge, to be re-circulated; this ensures rapid warming up. The thermostat opens at 120 to 140 deg. F. (49 to 60 deg. C.) and diverts some of the cooling water to waste and the temperature is maintained at the correct value. The vent pipe on the scavenge to prevent air lock is essential.

Waste water passes through the water-cooled silencer into the tail pipe and goes overboard with the exhaust.




FIG. 6

79

Exhaust. The exhaust system is a most important factor in the performance of a two-stroke engine. Installation instructions (page 10) must be carefully followed. From the manifold the exhaust passes through 3-in. of pipe to the silencer, which has a detachable cover for cleaning purposes. Brass coats the silencer and tail pipe.




FIG. 7

F10 **Gearbox.** The cast iron gearbox is bolted to the flywheel housing. The gear is of the epicyclic type, with cast iron cone clutches.

Reverse is controlled by a lever in a housing on top of the gearbox having straight face and all movements. The lever is cranked so that it can be either vertical when in neutral or else nearly horizontal. The filler plug is on top and the dipstick on the port side.

F11 The throttle mechanism, attached to the thermostat housing on the port side, is linked to the governor. To stop the engine, the reverse lever is moved to neutral and the red painted knob marked "stop" is pushed. Idle speed is set by the screw (R, Fig. 7) on the port side of the engine cover just above the water pump. Screwing inward raises the speed.

Electrical Equipment—Lamps 12 volt

F12 The Dynamo is belt driven by a pulley at the forward end. Belt tension is adjusted by rocking the dynamo. A scaled control unit regulates the output which depends on the state of the battery—high when the battery is low, tapering down to a trickle when the battery is fully charged.

The switchboard has an ammeter and oil pressure gauge.

A push button on the switchboard actuates the starter through a solenoid.



FIG. 8. Wiring Diagram.

F13 The Starter (Model M-408G) on the starboard side rotates the flywheel by a Bendis drive. The Bendis pinion is on a screwed sleeve carried on splines on the starter shaft. The sleeve can

travel along the shaft against a compression spring which cushions the shock of engagement with the gear ring on the flywheel.

When the starter switch is closed the shaft and sleeve rotate suddenly. Owing to inertia, the pinion does not rotate but slides along the screwed surface of the sleeve into engagement with the gear ring on the flywheel and rotates it.

As soon as the engine fires it runs away from the starter and causes the pinion to be screwed back along the sleeve out of engagement.

A starting handle at the forward end turns the engine by chain and a free wheel mechanism.

Blowring. The engine has two feet at the forward end of the crankcase and two on the flywheel housing. Great care has been taken over balancing the engine, which, as it has two firing cycles per revolution, is particularly free from vibration.




FIG. 9 Power Curve

METRIC EQUIVALENTS

of dimensions used in this book.


Inches	mm.	Inches	mm.	Inches	mm.	Inches	mm.
0.0005	0.0127	0.7480	19.01	0.7874	20.00	2.0000	50.80
0.0010	0.0254	0.7500	19.05	0.8867	22.50	2.0000	50.80
0.0015	0.0381	0.7520	19.10	1.0000	25.40	2.0000	50.80
0.0020	0.0508	0.7540	19.15	1.1188	28.42	2.0000	50.80
0.0025	0.0635	0.7560	19.20	1.2500	31.75	2.0000	50.80
0.0030	0.0762	0.7580	19.25	1.3862	35.20	2.0000	50.80
0.0035	0.0889	0.7600	19.30	1.5275	38.78	2.0000	50.80
0.0040	0.1016	0.7620	19.35	1.6750	42.55	2.0000	50.80
0.0045	0.1143	0.7640	19.40	1.8275	46.42	2.0000	50.80
0.0050	0.1270	0.7660	19.45	1.9862	50.20	2.0000	50.80
0.0055	0.1397	0.7680	19.50	2.1500	54.67	2.0000	50.80
0.0060	0.1524	0.7700	19.55	2.3188	59.00	2.0000	50.80
0.0065	0.1651	0.7720	19.60	2.4938	63.18	2.0000	50.80
0.0070	0.1778	0.7740	19.65	2.6750	68.00	2.0000	50.80
0.0075	0.1905	0.7760	19.70	2.8625	73.00	2.0000	50.80
0.0080	0.2032	0.7780	19.75	3.0562	77.80	2.0000	50.80
0.0085	0.2159	0.7800	19.80	3.2562	83.30	2.0000	50.80
0.0090	0.2286	0.7820	19.85	3.4625	88.50	2.0000	50.80
0.0095	0.2413	0.7840	19.90	3.6750	93.80	2.0000	50.80
0.0100	0.2540	0.7860	19.95	3.8938	99.20	2.0000	50.80
0.0105	0.2667	0.7880	20.00	4.1188	104.80	2.0000	50.80
0.0110	0.2794	0.7900	20.05	4.3500	110.60	2.0000	50.80
0.0115	0.2921	0.7920	20.10	4.5875	116.60	2.0000	50.80
0.0120	0.3048	0.7940	20.15	4.8312	122.80	2.0000	50.80
0.0125	0.3175	0.7960	20.20	5.0812	129.20	2.0000	50.80
0.0130	0.3302	0.7980	20.25	5.3375	135.80	2.0000	50.80
0.0135	0.3429	0.8000	20.30	5.6000	142.60	2.0000	50.80
0.0140	0.3556	0.8020	20.35	5.8688	149.60	2.0000	50.80
0.0145	0.3683	0.8040	20.40	6.1438	156.80	2.0000	50.80
0.0150	0.3810	0.8060	20.45	6.4250	164.20	2.0000	50.80
0.0155	0.3937	0.8080	20.50	6.7125	171.80	2.0000	50.80
0.0160	0.4064	0.8100	20.55	7.0062	179.60	2.0000	50.80
0.0165	0.4191	0.8120	20.60	7.3062	187.60	2.0000	50.80
0.0170	0.4318	0.8140	20.65	7.6125	195.80	2.0000	50.80
0.0175	0.4445	0.8160	20.70	7.9250	204.20	2.0000	50.80
0.0180	0.4572	0.8180	20.75	8.2438	212.80	2.0000	50.80
0.0185	0.4699	0.8200	20.80	8.5688	221.60	2.0000	50.80
0.0190	0.4826	0.8220	20.85	8.9000	230.60	2.0000	50.80
0.0195	0.4953	0.8240	20.90	9.2375	240.00	2.0000	50.80
0.0200	0.5080	0.8260	20.95	9.5812	249.60	2.0000	50.80
0.0205	0.5207	0.8280	21.00	9.9312	259.40	2.0000	50.80
0.0210	0.5334	0.8300	21.05	10.2875	269.40	2.0000	50.80
0.0215	0.5461	0.8320	21.10	10.6500	279.60	2.0000	50.80
0.0220	0.5588	0.8340	21.15	11.0188	290.00	2.0000	50.80
0.0225	0.5715	0.8360	21.20	11.3938	300.60	2.0000	50.80
0.0230	0.5842	0.8380	21.25	11.7750	311.40	2.0000	50.80
0.0235	0.5969	0.8400	21.30	12.1625	322.40	2.0000	50.80
0.0240	0.6096	0.8420	21.35	12.5562	333.60	2.0000	50.80
0.0245	0.6223	0.8440	21.40	12.9562	345.00	2.0000	50.80
0.0250	0.6350	0.8460	21.45	13.3625	356.60	2.0000	50.80
0.0255	0.6477	0.8480	21.50	13.7750	368.40	2.0000	50.80
0.0260	0.6604	0.8500	21.55	14.1938	380.40	2.0000	50.80
0.0265	0.6731	0.8520	21.60	14.6188	392.60	2.0000	50.80
0.0270	0.6858	0.8540	21.65	15.0500	405.00	2.0000	50.80
0.0275	0.6985	0.8560	21.70	15.4875	417.60	2.0000	50.80
0.0280	0.7112	0.8580	21.75	15.9312	430.40	2.0000	50.80
0.0285	0.7239	0.8600	21.80	16.3812	443.40	2.0000	50.80
0.0290	0.7366	0.8620	21.85	16.8375	456.60	2.0000	50.80
0.0295	0.7493	0.8640	21.90	17.3000	470.00	2.0000	50.80
0.0300	0.7620	0.8660	21.95	17.7688	483.60	2.0000	50.80
0.0305	0.7747	0.8680	22.00	18.2438	497.40	2.0000	50.80
0.0310	0.7874	0.8700	22.05	18.7250	511.40	2.0000	50.80
0.0315	0.8001	0.8720	22.10	19.2125	525.60	2.0000	50.80
0.0320	0.8128	0.8740	22.15	19.7062	540.00	2.0000	50.80
0.0325	0.8255	0.8760	22.20	20.2062	554.60	2.0000	50.80
0.0330	0.8382	0.8780	22.25	20.7125	569.40	2.0000	50.80
0.0335	0.8509	0.8800	22.30	21.2250	584.40	2.0000	50.80
0.0340	0.8636	0.8820	22.35	21.7438	599.60	2.0000	50.80
0.0345	0.8763	0.8840	22.40	22.2688	615.00	2.0000	50.80
0.0350	0.8890	0.8860	22.45	22.8000	630.60	2.0000	50.80
0.0355	0.9017	0.8880	22.50	23.3375	646.40	2.0000	50.80
0.0360	0.9144	0.8900	22.55	23.8812	662.40	2.0000	50.80
0.0365	0.9271	0.8920	22.60	24.4312	678.60	2.0000	50.80
0.0370	0.9398	0.8940	22.65	24.9875	695.00	2.0000	50.80
0.0375	0.9525	0.8960	22.70	25.5500	711.60	2.0000	50.80
0.0380	0.9652	0.8980	22.75	26.1188	728.40	2.0000	50.80
0.0385	0.9779	0.9000	22.80	26.6938	745.40	2.0000	50.80
0.0390	0.9906	0.9020	22.85	27.2750	762.60	2.0000	50.80
0.0395	1.0033	0.9040	22.90	27.8625	780.00	2.0000	50.80
0.0400	1.0160	0.9060	22.95	28.4562	797.60	2.0000	50.80
0.0405	1.0287	0.9080	23.00	29.0562	815.40	2.0000	50.80
0.0410	1.0414	0.9100	23.05	29.6625	833.40	2.0000	50.80
0.0415	1.0541	0.9120	23.10	30.2750	851.60	2.0000	50.80
0.0420	1.0668	0.9140	23.15	30.8938	870.00	2.0000	50.80
0.0425	1.0795	0.9160	23.20	31.5188	888.60	2.0000	50.80
0.0430	1.0922	0.9180	23.25	32.1500	907.40	2.0000	50.80
0.0435	1.1049	0.9200	23.30	32.7875	926.40	2.0000	50.80
0.0440	1.1176	0.9220	23.35	33.4312	945.60	2.0000	50.80
0.0445	1.1303	0.9240	23.40	34.0812	965.00	2.0000	50.80
0.0450	1.1430	0.9260	23.45	34.7375	984.60	2.0000	50.80
0.0455	1.1557	0.9280	23.50	35.4000	1004.40	2.0000	50.80
0.0460	1.1684	0.9300	23.55	36.0688	1024.40	2.0000	50.80
0.0465	1.1811	0.9320	23.60	36.7438	1044.60	2.0000	50.80
0.0470	1.1938	0.9340	23.65	37.4250	1065.00	2.0000	50.80
0.0475	1.2065	0.9360	23.70	38.1125	1085.60	2.0000	50.80
0.0480	1.2192	0.9380	23.75	38.8062	1106.40	2.0000	50.80
0.0485	1.2319	0.9400	23.80	39.5062	1127.40	2.0000	50.80
0.0490	1.2446	0.9420	23.85	40.2125	1148.60	2.0000	50.80
0.0495	1.2573	0.9440	23.90	40.9250	1170.00	2.0000	50.80
0.0500	1.2700	0.9460	23.95	41.6438	1191.60	2.0000	50.80
0.0505	1.2827	0.9480	24.00	42.3688	1213.40	2.0000	50.80
0.0510	1.2954	0.9500	24.05	43.1000	1235.40	2.0000	50.80
0.0515	1.3081	0.9520	24.10	43.8375	1257.60	2.0000	50.80
0.0520	1.3208	0.9540	24.15	44.5812	1280.00	2.0000	50.80
0.0525	1.3335	0.9560	24.20	45.3312	1302.60	2.0000	50.80
0.0530	1.3462	0.9580	24.25	46.0875	1325.40	2.0000	50.80
0.0535	1.3589	0.9600	24.30	46.8500	1348.40	2.0000	50.80
0.0540	1.3716	0.9620	24.35	47.6188	1371.60	2.0000	50.80
0.0545	1.3843	0.9640	24.40	48.3938	1395.00	2.0000	50.80
0.0550	1.3970	0.9660	24.45	49.1750	1418.60	2.0000	50.80
0.0555	1.4097	0.9680	24.50	49.9625	1442.40	2.0000	50.80
0.0560	1.4224	0.9700	24.55	50.7562	1466.40	2.0000	50.80
0.0565	1.4351	0.9720	24.60	51.5562	1490.60	2.0000	50.80
0.0570	1.4478	0.9740	24.65	52.3625	1		

TOOLS

Bolts and Nuts have U.N.F. threads, spacers being marked with dimension across flats. R.S.F. Spacers are provided for the hexagon headed plugs, used on the engine.

1	0	1080	Flat Spanner	$2\frac{1}{2} \times 2\frac{1}{2}$ R.S.F.		
2	0	1081	" "	$1\frac{1}{2} \times 1\frac{1}{2}$ "		
3	0	1082	" "	$1\frac{1}{2} \times 1\frac{1}{2}$ "		
4	0	1091	" "	$1\frac{1}{2} \times 1\frac{1}{2}$ "		
3	0	12000	Ring Spanner	$1\frac{1}{2}$ "		
3	0	1094	" "	$1\frac{1}{2}$ "		metric
1	0	1176-08	Flat Spanner	$2\frac{1}{2} \times 2\frac{1}{2}$ U.N.F.	44×20	A.P.
1	0	1176-03	" "	$1\frac{1}{2}$ "	34	"
3	0	1176-02	" "	$1\frac{1}{2} \times 1\frac{1}{2}$ "	38×15	"
3	0	1176-01	" "	$1\frac{1}{2} \times 1\frac{1}{2}$ "	38×14	"
1	0	1178-08	Box "	$1\frac{1}{2} \times 1\frac{1}{2}$ "	$1\frac{1}{2} \times 1\frac{1}{2}$	"
2	0	1178-03	" "	$1\frac{1}{2}$ "	$1\frac{1}{2}$	"
2	0	1178-01	" "	$1\frac{1}{2}$ "	$1\frac{1}{2}$	"
1	0	940	Turner Bar	$2\frac{1}{2} \times 1\frac{1}{2}$ long		
	0	1002	" "	$2\frac{1}{2} \times 1\frac{1}{2}$ "		
	0	802	Key, Crank Nuts	$\frac{1}{2}$ " A.P.		
	0	950	" "	$\frac{1}{2}$ "		
1	0	2297	" "	$1\frac{1}{2}$ "		
2	0	7700	Scraper			
6	0	7702	Files			
12	0	8404	Extractor, Piston Pin			
2	0	1277	"	Bearing Cap		
	0	M2400	"	Bolt $1\frac{1}{2} \times 1\frac{1}{2}$ long		
	0	M2500	"	" $1\frac{1}{2} \times 1\frac{1}{2}$ "		
3	0	1175	"	Nutlet Holder		
3	0	1242	Crutch, Tappet			
1	2	0	11707	Nutlet Chasing Kit in Holder		
7	0	802	Funnel, with Waterproof Gasket Filter			
6	0	1304	Oilcan			

FIG. 10
 Longitudinal section of the
 engine showing the
 arrangement of the
 valves and the
 connecting rods.



ROTON SIMON
 1884
 (Copyright 1884)

Guarantee

Stuart Turner, Ltd., undertake, within twelve months from date of delivery, to repair or replace any part which fails through defective workmanship or material (excluding accident, misuse or neglect) provided that the defective part is returned carriage paid to the Works with a written statement that a claim is made under this guarantee.

Liability is limited to the above guarantee.

Stuart Plants

are made in the following sizes:—

Type K	½ to 1½ B.H.P. Engines.
..	1000 Watt Lighting Plant.
..	1000
..	2½
Type Pa	1 to 2 B.H.P. Engines.
..	1000 Watt Lighting Plant.
Type Pz	1 to 3 B.H.P. Engines.
..	1½ K.W. Lighting Plant.
Type PzF	4 to 7 B.H.P. Engines.
..	1 K.W. Lighting Plant.

Marine Engines, ½, 4 and 6 B.H.P.

Pumps and Pumping Plants.

Small Centrifugal Pumps.

We shall be glad to send full specifications on request.

STUART TURNER, Ltd.

Makers

Henley-on-Thames, England

Telephone—222

Telegram—Stuar, Henley-on-Thames (3 words)

Printed in England 11/22 G. & Co.—1922

RENIZ MOTOR

TAMINI ATOLYESS

Indice de Scler (Contact)